



Assembly contact holder




Insert the crimped socket contacts into the equipped contact holder and snap into place.
Assignment according to ISO 12098.

After the socket contacts have snapped into place, please check the correct assignment and locking. If the spare parts kit is to be used for the 13-pin socket, slots 14 & 15 must be closed with the blind plugs.






Crimp



Crimp data according to specification tyco114-18020.




Assembly end cap / bayonet ring






Assembly





Assembly



Slide the bayonet ring and end cap onto the housing. Turn the bayonet ring onto the housing.

Bayonet domes have to lock into place.